Instructions for wear checks of play equipment		The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		1.	, , ,		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.		2.	splinters and round off scratches from sharp edges. Recommendation: apply wood preservative wax (www.complex-farben.com) once a year.		
Intervals for maintenance work and checks generally depend on			Bearing		
- the location - the usage - the frequency of use - possible vandalism		3.	Check for smooth operation.		
		1	Check bolts and screws of the fixture for wear		
For more details see also "General instructions for maintenance of		4.	and tear and ensure they are tight. Retighten if necessary (see detailed diagram).		
playgrounds". Rotating Discs		5.	Clean the lacquered surface with a car varnish (www.sonax.de).		
with wooden frame	Order No. 40 22500	6.	Repair damaged areas with an acrylic varnish in a matching colour.		
Order No. 10.22100 Spiral	Order No. 10.22500 Funnel		Structural stability		
Order No. 10.22200 Funnel	Order No. 10.22600 Pulsation 2	7.	In order to check the posts for rot, uncover the foundations once a year.		
Order No. 10.22300 Pulsation	Order No. 10.22700 Pulsation 2				
Order No. 10.22400 Colour Disc	Order No. 10.22800 Spiral 2				ဖွ
5 6	detailed diagram				Special notes, e.g. for repairs
2			pair not carried out, s still possible to play on equipment		
			pair not carried out, uipment is taken out of action		
			work carried out, erything is in order		
			Maintenance carried out by:		
For spare parts refer to back of page.			Date		

Spare Parts Rotating Discs Order No. 10.22100 -10.22800



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.

Order No. Spare part

10.99913 rotating disc

please indicate the motif

