This copy may be copied for maintenance of Richter play equipment. Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Playground..... Screws/bolts Date of installation 1. Check that all bolts and screws are tight and retighten if necessary. Checks depend on the type of equipment. Any equipment with moving parts must Stainless steel be checked at least twice a year, static equipment at least once a year. 2. Clean with stainless steel spray using a clean cloth. Intervals for maintenance work and checks generally depend on **Mirrors** - the location Clean with standard glass cleaner using a - the usage lint-free cloth. Polish any clouding on the - the frequency of use surface of the mirror using a fine metal polish. - possible vandalism Structural stability For more details see also "General instructions for maintenance of Check anchoring to the ground once a year playgrounds". Walk-in Kaleidoscope Order No. 10.23410 mirrors only inside 2 Special notes, e.g. for repairs Walk-in Kaleidoscope Order No. 10.23420 mirrors inside and outside Repair not carried out, it is still possible to play on equipment Repair not carried out, 1 equipment is taken out of action All work carried out, 3 everything is in order

Maintenance carried out by:

..... Date