Instructions for wear checks of play equipment		The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Stainless steel			
Date of installation	1.	Clean with stainless steel spray using a clean cloth.			
Checks depend on the type of equipment. Any equipment with moving parts must		Operation			
be checked at least twice a year, static equipment at least once a year.	2.	Check that discs move smoothly.			
Intervals for maintenance work and checks generally depend on		Structural stability			
<ul><li>the location</li><li>the usage</li><li>the frequency of use</li><li>possible vandalism</li></ul>	3.	In order to ensure that the equipment is securely fastened to the ground and to check the foot for corrosion, uncover the foundation once a year.			
For more details see also "General instructions for maintenance of playgrounds".					
Big Sickle Disc Order No. 11.06000					
				otes, e.g. for repairs	

## Special no Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order Maintenance carried out by: