For spare parts refer to back of page.

## This copy may be copied for maintenance of Richter play equipment. Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Wooden parts Playground..... 1. Check for rot and, if necessary, smooth out Date of installation ..... splinters and round off sharp edges of cracks. Checks depend on the type of equipment. **Recommendation:** apply paraffin wax to the Any equipment with moving parts must upper end grain areas once a year, please be checked at least twice a year, static refer to order No. 0.90100, 1 litre. equipment at least once a year. Intervals for maintenance work and checks Ropes and rope connections generally depend on 3. Check ropes for wear and tear, if the steel - the location reinforcement is damaged, it is imperative it - the usage be replaced. - the frequency of use - possible vandalism 4. Check that ropes are securely connected, retighten screws/bolts if necessary. For more details see also "General instructions for maintenance of Structural stability playgrounds". 5. Uncover the foundation once a year in order to check for rot or the steel feet for corrosion. **Double Hanging Rope** Order No. K6.51900/L6.51900 2 3 (1 1 Special notes, e.g. for repairs Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order

Maintenance carried out by:

...... Date ......

Spare parts Double Hanging Rope Order No. K6.51900/L6.51900	Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to <b>only use original parts</b> .
Order No. Spare part	
0.92190 hanging rope with fastening on both ends	