Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground	Wooden parts		
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	Check the screw and bolt connections to the base equipment for firmness, thighten if necessary.		
Intervals for maintenance work and checks generally depend on - location	Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.		
usagefrequency of use	Sand Wheel		
- possible vandalism	4. Check that equipment rotates smoothly		
For more details see also our general	(brass bushes)		
instructions for maintenance of playgrounds!	5. Check welded seams for stability (cracks). If required have welding repairs carried out by a qualified person and sand down.		
Upper part of sand tray attached at building sites			
Order No. 5.97070 without walls Order No. 5.97071 over walls			
1 1 1			Special notes, e.g. for repairs
Upper part of sand tray			Ø
Order No. 5.97073	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		
Sand Wheel Order No. 5.97130	All work carried out, everything is in order		
**	Maintenance carried out by:		
For spare parts refer to back of page.	Date		

Spare parts Upper part of sand tray, Sand Wheel Order No. 5.97070/5.97071/5.97130	Please note that the safety standards of the equipmen must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .	
Order No. Spare parts		
0.97070 Sand tray		
0.97130 Sand wheel		